
Volume Target

When a volume is placed in a move from its' current location to another location, that other location is a target location until the volume is has a confirmed arrival.

If slotting is enabled the target location will, when a slot is assigned, include the slot allocation details as well.



From:
https://rtfm.tapetrack.com/ - **TapeTrack Documentation**

Permanent link:
https://rtfm.tapetrack.com/object/volume_target?rev=1525223359

Last update: **2025/01/21 22:07**